

## CONN-WELD OIL CAPACITY CHART



**THE CHART BELOW GIVES APPROXIMATE VOLUMES ONLY.**

**GO BY OIL CHECK PLUG AS INDICATED ON MECHANISM AND CHECK OIL LEVEL ON REGULAR MAINTENANCE INSPECTIONS. ADD OIL IF NECESSARY.**

**OVER/UNDER FILLING WILL BE DETRIMENTAL TO THE OPERATION OF YOUR MECHANISM AND WILL JEAPORDIZE WARRANTY**

<b>MECHANISM SERIES</b>	<b><u>APPROXIMATE OIL CAPACITY</u></b>
<b>1000</b>	4 U.S. QUARTS
<b>1500</b>	3 U.S. QUARTS
<b>2000</b>	5 U.S. QUARTS
<b>2500</b>	7 U.S. QUARTS
<b>3000</b>	11 U.S. QUARTS

## RECOMMENDED OIL CHANGE INTERVALS

Conn-Weld recommends oil changes as follows:

1. Initial oil change after 300 operating hours.
2. Subsequent oil changes every 1000 operating hours.

NOTE: Extreme or unusual operating environments could necessitate more frequent oil changes. Contact Conn-Weld for advice.