

CONN-WELD RECEIVING AND STORAGE INSTRUCTIONS

INSPECT FOR DAMAGE DURING SHIPMENT

Conn-Weld G-Master Vibrating Screens are thoroughly inspected prior to shipment; However, loss or damage may occur during shipping. It is important to do the following upon receiving:

- Check shipment for visible damage
- Account for all items listed on shipping documents
- Report damages or shortages immediately to carrier

SPECIAL TOOLS

Installation of assembled equipment does not require special tools. Standard mechanics tools are all that is required (sockets, wrenches, hammers, etc...). Conn-Weld recommends a Huck Gun and Hydraulic Wrench Power Unit Assembly for replacement and installation of major components. Conn-Weld does not supply but you may contact our purchasing department for information on where to obtain.

STORAGE

G-Master Mechanisms



The mechanism is shipped from the factory with a corrosion inhibitor in the oil for the protection of internal parts during storage. This oil should be replaced with proper operating oil before starting the machine.

NOTE: If mechanism(s) need longer than four weeks before start-up, completely drain each mechanism of all oil and refill with a corrosion inhibiting oil. If unable to locate corrosion inhibiting oil, please contact Conn-Weld Industries. When ready to commission drain oil completely and follow Conn-Weld's standard oil specification supplied in this manual.

Refer to maintenance section for oil change schedule.

Urethane Panels

If your equipment comes installed with urethane panels Conn-Weld recommends the following:

Up to 8 weeks:

Cover with weather resistant tarp to divert direct sunlight

8 weeks to 12 months:

Option 1 Store equipment inside warehouse

Option 2 If storage space is unavailable then urethane panels should be removed and stored in warehouse until ready to commission

Rubber Components

Components such as V-Belts and Rubber Buffers should be protected from extreme heat, sunlight, or any chemical, oil, and grease that will deteriorate rubber compounds.

Wooden Crates

If crates are not being warehoused, then the following steps should be taken:

- Set crate on pallet or accommodating platform to keep from directly setting on ground surface.
- Cover with weather resistant tarp.

NOTE: Conn-Weld makes every effort to predetermine conditions that may have any bearing on warranty of equipment, parts, and components. However, it is the responsibility of the customer to take any questionable consideration into account by contacting Conn-Weld personnel and react accordingly.

